


**Connections  
for Trainee  
desks.**



**Note: The "Bus Out" of the last Trainee Link Control may either return to the Auto-Splitter or the Logic Control Board at the Instructor Station depending on the configuration of your system. See Auto-Splitter drawing for correct placement.**

Technical Assistance  
1-800-237-5465  
www.acs-linksystems.com