

Connections for Trainee desks.



Note: The "Bus Out" of the last Trainee Link Control may either return to the Auto-Splitter or the Logic Control Board at the Instructor Station depending on the configuration of your system. See Auto-Splitter drawing for correct placement.

Technical Assistance
1-800-237-5465
www.acs-linksystems.com

